

Mass Storage Utilities

211067A

Date: 861111

Report no: 1

Program: DISC-TEMA-I00
Subject: Corrected errors, new program revision: I10
 new product revision: A01

Description:

The FORMAT command in DISC-TEMA-I00 does not work properly on CDC - EMD-9720 disks. The actual disk names, as used in DISC-TEMA, are as follows:

DISC-288MB-x-E (x = 1,2,3 or 4)
DISC-4-70MB-x-E

Symptom:

Reallocated tracks are placed on cylinder 1208d instead of cylinder 1207d.

Summary:

For formatting of CDC - EMD-9720 disks, please use:

Product name: 211067A01 MASS STORAGE UTILITIES
Program name: 203134I10 DISC-TEMA-I10

(or later revisions)